

Dantoin™ BCDMH RW Tablets Industrial Water Treatment Microbiocide



BCDMH RW Tablets

Dantoin™ BCDMH RW Tablets control microbiological growth and slime formation in industrial, commercial, beverage and municipal water treatment applications.

Application

- Manual dosing applications.
- For use in all industrial feeders designed for bromine (BCDMH) tablets.

Approved uses include:

Dantoin™ BCDMH RW Tablets aids in the control of bacterial, fungal and algal slimes in commercial and industrial cooling towers; heat exchange water systems; evaporative condensers; influent systems such as flow through filters, cooling ponds, canals and lagoons; industrial water scrubbing systems; brewery pasteurizers; sewage systems (septic tanks, leach fields, tank lines, sewers, lagoons, and sewage effluent water); photo—processing wash water; food and non—food contact paper and paper process wash water; industrial air washing systems equipped with a mist eliminator; cannery cooling water, package warmers, pasteurizer water and retort water; once—through industrial cooling water systems; water features; commercial air conditioner and dehumidifier basins or drip pans and wastewater treatment systems.

Typical Properties	
Appearance:	Solid off—white tablets
UN Number Local:	3085
Molecular Formula:	$C_5 H_6 BrCIN_2 O_2$
Molar Mass:	241.47 g/mol
Density:	1.6 g/cm³
Melting Point:	159–163 ° C
Solubility in Water:	0.25 g/100g at 25°C

www.lonza.com

www.lonzawatertreatment.co.za

Advantages

- Effective over a broad pH and alkalinity range, including highly cycled water systems.
- Effective in the presence of ammonia and other nitrogenous substances.
- Hydantoin stabilization reduces product consumption by halogen demand and increases compatibility with process additives.
- Hydantoin controlled release of biocide improves the broad distribution of halogen residuals.
- Solid form minimizes the potential for worker exposure, spills or other environmental releases.
- High activity in a solid concentrate reduces storage and transportation costs.
- High active ingredient.
- Stable product.

Regulatory

- EPA Registration No. 6836-317.
- EINECS No. 251-171-5.
- FDA Approval under 21 CFR 176.300 as slimicide in the production of paper and board intended to contact food

Storage

Please see the MSDS for detailed information. Dantoin™ BCDMH RW Tablets remain stable provided it is stored in a cool, dry, well—ventilated area out of the sun and heat. Similar to other halogen generators, Dantoin™ BCDMH RW Tablets will decompose if mixed with readily oxidizable substances. Avoid mixing Dantoin™ BCDMH RW Tablets with organics, petroleum—based lubricating oils, strong acids, strong alkalis, reducing agents, and hydrated salts.

Safety And First Aid Measures

Please consult product MSDS

Packaging

Dantoin $^{\text{\tiny{M}}}$ BCDMH RW Tablets are available in 25kg drums.

Product Code

Dantoin™ BCDMH RW Tablets: BCDMH25.



Dantoin™ BCDMH RW Tablets control bacterial, fungal and algal slimes in water systems, for use in commercial, industrial and municipal applications.

Arch Chemicals (Pty) Ltd, a Lonza company South Africa

NCP Factory Site, 9 Hytor Road ZA – 1624 Kempton Park Tel: + 27 11 393 9000

Fax: +27 11 393 9073

The information contained herein is believed to be correct and corresponds to the latest state of scientific and technical knowledge. However, no warranty is made, either expressed or implied, regarding its accuracy or the results to be obtained from the use of such information. Some products may not be available in all markets or for every type of application. Any user must make his own determination and satisfy himself that the products supplied by Lonza Group Ltd and its affiliates, and the information and recommendations given by Lonza Group Ltd and its affiliates, are [i] suitable for intended process or purpose, [ii] in compliance with environmental, health and safety regulations, and (iii) will not infringe any third party's intellectual property rights. Dantoin" is a trademark of Lonza or its affiliates.

© 2015 Lonza